

any discrepancies should be reported

site/survey based on ordnance survey information provided by prodat systems plc, (www.promap.co.uk) prodat does not guarantee that all past or current uses or features will be

or used as a substitute for any physical

commencement of work

identified in the product

investigation or inspection.

drawings to be read in accordance with the

criteria set for air permeability.

when printing off pdf's.

sized sheet.

correctly.

© HERTFORD PLANNING SERVICE

all dimensions should be checked on site prior to

the product does not give details about the actual state or condition of the site nor should it be used or taken to indicate or exclude actual suitability or unsuitability of the site for any particular purpose, or relied upon for determining salability or value,

dwelling emission rate (der/ter) calculation. the

building must be built 'as designed' meeting the

it is the responsibility of the user to verify that the resulting prints are to scale on the appropriate

also that the scale bars on the plan measure

immediately

First Floor Plan

